



- Phase RC (disconnect RH and RC (AB) if RC exist)
 - Phase RH (keep shorted RH and RC (AB) if no RC)
 - Neutral
 - To external IR reciver
 - Alarm out (dry contact N. open)
 - Not in use
- 24v AC